

56508364 - Right Side Broom Guard Kit

SW8000 Models: ALL

Exterra™ Models: ALL

SR 1900 Models: ALL

CONTENTS OF KIT

Item	Ref. No.	Qty	Description
[]	56040922	1	Instruction Sheet
1	56409335	1	Bumper
2	56409336	1	Pin
3	56002055	1	Wsh, Flt Std 3/8
4	56002800	2	Scr, Hex SS 3/8-16 X 2.00
5	56003783	3	Scr, Hex SS 3/8-16 X 3.00
6	56002769	5	Nut, Hex Nyl Loc 3/8-16
7	56003266	2	Ring, Ret Ext Type E 0.75 Dia.
8	56009242	4	Wsh, Flt .406 X 1.500 X .125
9#	56107726	1	RT SB Guard Weldt

[] = Not Shown

= Revised or new since last update

56508365 - Left Side Broom Guard Kit

SW8000 Models: ALL

Exterra™ Models: ALL

SR 1900: ALL

CONTENTS OF KIT

Item	Ref. No.	Qty	Description
[]	56040922	1	Instruction Sheet
1	56409335	1	Bumper
2	56409336	1	Pin
3	56002055	1	Wsh, Flt Std 3/8
4	56002800	2	Scr, Hex SS 3/8-16 X 2.00
5	56003783	3	Scr, Hex SS 3/8-16 X 3.00
6	56002769	5	Nut, Hex Nyl Loc 3/8-16
7	56003266	2	Ring, Ret Ext Type E 0.75 Dia
8	56009242	4	Wsh, Flt .406 X 1.500 X .125
10#	56107727	1	LT SB Guard Weldt

[] = Not Shown

= Revised or new since last update

NOTE: Items 1, 2 & 7 are pre-assembled to the side broom guard weldment in both kits.

INSTALLATION INSTRUCTIONS

WARNING!

DISCONNECT BATTERY BEFORE SERVICING.

- 1 Remove the side brooms to allow better access.
- 2 **See Figure 1.** Place the Weldment (**9 or 10**) onto the corner of the machine's hopper at the location shown. Make sure the weldment is flush to all three surfaces (top, front and side). Using the weldment holes as a template mark the five hole locations. Drill the five pilot mounting holes using a $\varnothing 7/16$ " drill bit.
- 3 Assemble the side broom guard to the machine using the hardware items (**3, 4, 5, 6 & 8**) as shown. Note that there are different length mounting screws. The shorter Screws (**4**) are used on the side of the guard. Replace the side brooms.

FIGURE 1

