

ORDER#	LINE	BSHP SERIAL NUMBER	RTM PART NUMBER	Hose Group
<b>Box 1 (Hydraulic Steering Assy.)</b>				
69077982-00	1	HP0962	84315C-191	Hydraulic Steering Assy.
69077982-00	2	HP0941	84303C-197	Hydraulic Steering Assy.
69077982-00	3	HP0982	84315C-203	Hydraulic Steering Assy.
69077982-00	4	HP0983	84315C-197	Hydraulic Steering Assy.
69077982-00	5	HP0149	84301A-202	Hydraulic Steering Assy.
69077982-00	6	HP6900RT002	85190H-115	Hydraulic Steering Assy.
69077982-00	7	HP6900RT022	84341F-055	Hydraulic Steering Assy.
69077982-00	8	HP3434	84341F-057	Hydraulic Steering Assy.
69077982-00	9	HP6900RT023	84330F-016	Hydraulic Steering Assy.
69077982-00	10	HP6900RT025	84330F-079	Hydraulic Steering Assy.
69077982-00	11	HP3359	84330F-048	Hydraulic Steering Assy.
69077982-00	12	HP6900RT024	84330F-048	Hydraulic Steering Assy.
69077982-00	13	HP6900RT014	84340G-052	Hydraulic Steering Assy.
69077982-00	14	HP6900RT026	84340G-062	Hydraulic Steering Assy.
69077982-00	15	HP6900RT027	84301F-087	Hydraulic Steering Assy.
69077982-00	16	HP6900RT003	84376H-100	Hydraulic Steering Assy.
69077982-00	17	HP0096	84303A-140	Hydraulic Steering Assy.
69077982-00	18	HP0127	84317A-107	Hydraulic Steering Assy.
69077982-00	19	HP1038	84303C-036	Hydraulic Steering Assy.
69077982-00	20	HP0144	84315A-130	Hydraulic Steering Assy.
<b>Box 2 (Supplemental DC Pump Assy.)</b>				
69077982-00	21	HP6900RT019	84303C-073	Supplemental DC Pump Assy.
69077982-00	22	HP6900RT020	84303C-088	Supplemental DC Pump Assy.
69077982-00	23	HP6900RT018	84387F-084	Supplemental DC Pump Assy.
<b>Box 3 (Hydraulic Brake Assy.)</b>				
69077982-00	24	HP2487	84315B-119	Hydraulic Brake Assy.
69077982-00	25	HP0136	84301A-126	Hydraulic Brake Assy.
69077982-00	27	HP2543	84315B-183	Hydraulic Brake Assy.
69077982-00	28	HP1006	84315C-118	Hydraulic Brake Assy.
69077982-00	29	HP0118	84317A-035	Hydraulic Brake Assy.
69077982-00	30	HP0110	84303A-040	Hydraulic Brake Assy.
69077982-00	31	HP6900RT031	84303F-169	Hydraulic Brake Assy.
69077982-00	32	HP2721	84315B-097	Hydraulic Brake Assy.
69077982-00	33	HP2745	84315B-161	Hydraulic Brake Assy.
69077982-00	34	HP0102	84659B-128	Hydraulic Brake Assy.
69077982-00	35	HP0128	84659B-128	Hydraulic Brake Assy.
69077982-00	36	HP0146	84661B-036	Hydraulic Brake Assy.
69077982-00	37	HP0098	84661B-036	Hydraulic Brake Assy.
69077982-00	38	HP2550	84301B-260	Hydraulic Brake Assy.
69077982-00	39	HP2536	84315B-263	Hydraulic Brake Assy.
69077982-00	40	HP6900RT030	84303F-169	Hydraulic Brake Assy.
69077982-00	41	HP2740	84315B-064	Hydraulic Brake Assy.
69077982-00	42	HP0935	84315C-060	Hydraulic Brake Assy.
69077982-00	43	HP2478	84317B-066	Hydraulic Brake Assy.
69077982-00	44	HP2673	84301B-072	Hydraulic Brake Assy.
69077982-00	45	HP6900RT028	84301F-067	Hydraulic Brake Assy.
69077982-00	46	HP6900RT021	84301F-074	Hydraulic Brake Assy.

69077982-00	47	HP0122	84303A-031	Hydraulic Brake Assy.
69077982-00	48	HP6900RT029	84303F-100	Hydraulic Brake Assy.

**Box 4 (Hydraulic Dump Assy.)**

69077982-00	49	HP6900RT007	84360J-069	Hydraulic Dump Assy.
69077982-00	50	HP6900RT006	84360J-079	Hydraulic Dump Assy.
69077982-00	51	HP6900RT008	84360K-052	Hydraulic Dump Assy.
69077982-00	52	HP6900RT001	56427	Hydraulic Dump Assy.
69077982-00	53	HP6900RT005	84360J-073	Hydraulic Dump Assy.
69077982-00	54	HP6900RT004	84360J-124	Hydraulic Dump Assy.
69077982-00	55	HP6900RT009	84361H-081	Hydraulic Dump Assy.
69077982-00	56	HP6900RT013	84361H-125	Hydraulic Dump Assy.
69077982-00	57	HP6900RT011	84315C-182	Hydraulic Dump Assy.
69077982-00	58	HP6900RT012	84315C-059	Hydraulic Dump Assy.
69077982-00	59	HP6900RT017	84315C-182	Hydraulic Dump Assy.
69077982-00	60	HP6900RT010	84315C-051	Hydraulic Dump Assy.
69077982-00	61	HP6900RT015	84315C-189	Hydraulic Dump Assy.
69077982-00	62	HP6900RT016	84315C-056	Hydraulic Dump Assy.

**Box 5 (Engine Piping Assy.)**

69077982-00	63	HP6900RT038	54479	Engine Piping Assy.
69077982-00	64	HP6900RT044	1038609	Engine Piping Assy.
69077982-00	65	HP6900RT045	17826	Engine Piping Assy.
69077982-00	66	HP6900RT039	17826	Engine Piping Assy.
69077982-00	67	HP6900RT035	54482	Engine Piping Assy.
69077982-00	68	HP6900RT041	26553	Engine Piping Assy.
69077982-00	69	HP6900RT034	54480	Engine Piping Assy.
69077982-00	70	HP6900RT043	54481	Engine Piping Assy.
69077982-00	71	HP6900RT062		Engine Piping Assy.

**Box 6 (Hydraulic Cooler Assy.)**

69077982-00	72	HP6900RT040	84306G-177	Hydraulic Cooler Assy.
69077982-00	73	HP6900RT033	84303G-269	Hydraulic Cooler Assy.
69077982-00	74	HP6900RT032	84303G-165	Hydraulic Cooler Assy.

**Box 7 (Hose P/U)**

69077982-00	75	HP6900RT050		Hose P/U
69077982-00	76	HP6900RT051	Oil Burner	Hose P/U
69077982-00	77	HP6900RT052	FUEL COOLER	Hose P/U
69077982-00	78	HP6900RT053	FUEL COOLER	Hose P/U
69077982-00	79	HP6900RT054	Coolant	Hose P/U
69077982-00	80	HP6900RT055	Coolant	Hose P/U
69077982-00	81	HP6900RT056	Oil Burner	Hose P/U
69077982-00	82	HP6900RT057	Fuel Line Return to Tank	Hose P/U
69077982-00	83	HP6900RT060		Hose P/U
69077982-00	84	HP6900RT048		Hose P/U
69077982-00	85	HP6900RT049		Hose P/U
69077982-00	86	HP6900RT061		Hose P/U